

MINA

ORBIT

USER MANUAL



SPECIFICATIONS

Product Material	Silicone, ABS Plastic (Phthalate-free)
Waterproof Property	IPX6
Functional Pattern	3 speeds + 6 patterns of vibration
Power Supply Mode	Magnetic charging
Charging Time	Vibrator: About 120 minutes Cock Ring About 90 minutes
Battery Discharge Time	About 60 minutes
Packing List	Vibrator ×1, Charging Cable × 1
Product Size	Insertable length: 12cm / 4.7 inches Insertable diameter: 3.5cm / 1.38 inches Insertable circumference: 11cm / 4.33 inches

Congratulations on acquiring the Mina Orbit. Before getting more closely acquainted with it, please take a moment to look through this user manual.

BEFORE USING


- Please kindly read the manual before using this product.
- Fully charge before the first use. Wash with Toy Cleaner, body wash or soap.
- Check the equipment for damage before or after use and do not use the equipment if damage is found.

SAFETY & ATTENTION

- **Adult Use Only:** This product is prohibited for minors under the age of 18. Please keep the product out of the reach of children.
- **Personal Comfort:** If you experience some discomfort while using the device, please stop using the device immediately.
- **Battery Care:** This product has a built-in polymer lithium battery, which cannot be disassembled by itself to avoid damage to the product.
- **PLEASE NOTE:** Do not use the product while charging..

GETTING TO KNOW YOUR DEVICE

The Mina Orbit incorporates a multi-part vibrator and cock ring system, delivering a dynamic experience with 3 speeds and 6 patterns of vibration.



HOW TO USE

1. **Vibrator:** Press and hold on the power button on the vibrator for 1.5s to power on; it taps once then stops, the button light stays on and it is now in stand by mode. Short press for mode 1 (tapping & vibration) short press again to cycle through 10 modes (1-10-1) The light flashes with the tapping frequency after each mode. Press and hold for 1.5s to power off.
2. **Cock Ring:** Press and hold for 1.5 seconds to power on; it vibrates once and then stops, the button light stay's on and is in stand by mode. Short press again to cycle for Mode 1 (vibration), short press again to cycle through 10 modes (1-10-1). Light flashes with tapping fequency after each mode. Press and hold the power button for 1.5 seconds to power off.

CHARGING YOUR DEVICE

- The product is charged with a USB cable.
- Please charge it with the matching charger.
- When charging begins, the switch button LED lights will start flashing.
- When fully charged, the ON/OFF button LED is on constantly.
- The device is fully charged for approximately 60 minutes of pleasure.

CLEANING & STORAGE

- The Mina Orbit is IPX6 waterproof for easy maintenance.
- Wash with toy cleaner, body wash or soap. Don't use corrosive detergents.
- Please keep the product in a clean and dry place. Avoid direct sunlight.
- To prevent environmental harm and potential fire hazards, do not dispose of this product in standard household trash; instead, take it to a designated e-waste recycling facility equipped to handle lithium batteries.